



N

Note: Boundaries between outlet basins are shown as accurately as possible. In order to apply the correct outlet capacity for projects located near the boundaries between outlet basins, the design engineer must consult the sewer atlas and drain atlas to confirm which outlet basin receives drainage from the project site.

**Central Map for Release Rate -
Outlet Sewer Capacity
City of Chicago**
Department of Water Management